

CorrSen meter

Before using the device, read the user manual carefully and ensure that you only operate the device in accordance with the instructions.

Do not place the device in areas with excessive vibrations, as this could damage it.

Do not expose the device to excessive pressure, impact, dust, or high temperatures, as these factors could cause the product to malfunction, shorten its service life, damage the battery, or deform plastic parts.

Do not place open flames on the device.

Do not tamper with the internal electrical circuits of the device or replace the batteries yourself. Doing so could damage the device and automatically void the warranty. The device should only be repaired by a qualified professional.

Use a slightly damp soft cloth to clean the plastic parts of the device. Do not touch the sensor. Do not use solvents or cleaning agents, as they may damage the plastic parts and electrical circuits.

Do not immerse the device in water or other liquids. Do not expose the product to dripping or splashing water.

If the device is damaged or defective, do not attempt to repair it yourself. Take it to the retailer or manufacturer where you purchased it for repair.

Keep the product out of the reach of children; it is not a toy.

Safety data sheet



Do not dispose of the device in municipal waste, fire, disassemble it, or short-circuit it. Return unused devices to the appropriate collection point or send them to the manufacturer for environmentally friendly disposal.

Keep out of reach of children.

This device is not intended for use by persons (including children) whose physical, sensory, or mental incapacity or lack of experience and knowledge prevents them from using the device safely unless they are supervised or instructed in the use of the device by a person responsible for their safety.